

2004-5 Yamaha FJR1300 Race (no cut) Frame Sliders Install Instructions

Article by: Roland Lee

These sliders have been designed to offer unsurpassed protection for your Yamaha FJR1300 in the unfortunate event of a lowside or tip over. Motovation frame sliders are designed and manufactured by a company that only makes frame sliders. Each and every model is tested for drop and slide protection. They are tough but not brittle and can also absorb a huge impact. Sportsriders around the world who have tested various models of our products on the track have all given their thumbs up after experiencing first hand, the benefits of Motovation Frame Sliders.

Please read all instructions before beginning work! These frame sliders are designed to fit specific engine mounts of your Yamaha FJR1300. This kit has separate left and right pieces (left and right while sitting on the bike). It is highly recommended that you refer to your service manual before performing this installation. If you are unsure about the tightening torque, check your motorcycle's manual or www.motovationusa.com/torque.html for a quick reference guide.

Included in this kit:

- 2 x Left/ Right side frame sliders
- 2 x thicker aluminum spacers (Left)
- 2 x thinner aluminum spacers (Right)
- 2 x Left/ Right Hi Grade aluminum brackets
- 3 x m12 x 80mm socket head cap screws
- 1 x m12 x 70mm socket head cap screw
- 2 x m10 x 50mm socket head capscrews for sliders.

Tools Required:

- Torque Wrench
- 12mm allen key for Torque Wrench
- 14mm socket
- Phillips screw driver

INSTRUCTIONS: Attempt this install one side at a time.

- 1)
Remove both side fairings.
Remove left side original bolts. Leave original washers in place.
Install the supplied spacers as shown:
Left Side Spacers x 2 pcs (thicker ones).
Right Side Spacers x 2 pcs (thinner ones).
- 2)
Install the left side bracket with the thicker spacers as shown.
Tighten to manufacturer's recommended torque. (40ft/lbs)
Using the supplied M12 x 80mm bolts.
- 3)
Remove right side original bolts. Leave original washers in place.
Install the right side bracket with the thinner spacers as shown
Tighten to manufacturer's recommended torque.(40 ft/lbs)
Using the supplied 1 x M12 x 70mm bolt for the upper location.
Using the supplied 1 x M12 x 80mm bolt for the lower location.
- 4)
Re-install the left and right fairings to their original locations. This will leave only the mounting locations for the frame sliders visible on both sides.
- 5)
Install the supplied frame sliders with the remaining bolts and tighten.
Do not overtighten.

Motovation Accessories is a distributor for Yamaha frame sliders and accessories: <http://www.motovationUSA.com>
For detailed installation pictures, go to: http://www.motovationusa.com/Install_FSY05S_FJR1300.html